

Miscellaneous

Drill chuck



*Europe **North & South America

Drill chuck		Chuck key
Package type	Bulk	Bulk
Part No.	Part No.	Part No.

For Model:
6010D, 6409

192970-8	-	763418-3
----------	---	----------

For Model:
DP2010

192887-5	763077-3	763418-3
----------	----------	----------

For Model:
6013B/BR, 6300-4, 6301, 6305, 8406/C, 8416, DP4700, HP2010N

192877-8	-	763432-9
----------	---	----------

For Model:
6304LR, DA4000LR

193318-7	-	763432-9
----------	---	----------

For Model:
6501

192887-5	763077-3	763418-3
----------	----------	----------

For Model:
DA3010/F, DDA340, DDA350

-	763174-5	763415-9
---	----------	----------

For Model:
DP3002

-	-	763434-5
---	---	----------

For Model:
DA4030, DA4031

-	-	763432-9
---	---	----------

For Model:
DA4000LR, DS4000

**193319-5	-	763434-5
------------	---	----------

For Model:
DP4000, DP4002

-	-	763434-5
---	---	----------

For Model:
DP4010, HP2050, HP2051

193067-6	-	-
----------	---	---

For Model:
HP1620/F

192541-1	763142-8	-
----------	----------	---

For Model:
HP2050/F, HP2070/F, HP2071/F

*193822-6	-	763430-3
-----------	---	----------

193067-6	-	763430-3
----------	---	----------

For Model:
HP1630

195081-8	763161-4	763441-8
----------	----------	----------

For Model: DS4012

-	-	763430-3
---	---	----------

Carbon brush



High Volt CB No.	Part No.	Low Volt CB No.	Part No.
1	181019-9	1	181019-9
51	181021-2	76	191947-0
55	181026-2	75	191956-9
64	191627-8	75	191956-9
65	191628-6	76	191947-0
70	191914-5	70	191914-5
85	191998-3	75	191956-9
100	181030-1	124	191945-4
106	181410-1	107	181437-1
132	191972-1	132	191972-1
153	181044-0	154	181047-4
154	181047-4	154	181047-4
165	191936-5	166	191968-2
203	191953-5	203	191953-5
253	194547-5	253	194547-5
303	191963-2	303	191963-2
-	-	311	191979-7
325	194074-2	325	194074-2
411	191940-4	408	191938-1
415	191950-1	401	191910-3
419	191962-4	407	191927-6
459	194722-3	458	194721-5

Auto Cut- out Carbon Brush

105	181038-5	105	181038-5
113	191904-8	113	191904-8
155	181048-2	155	181048-2
173	195483-8	172	195100-0
175	195844-2	175	195844-2
204	191957-7	204	191957-7
327	194285-9	304	191961-6
318	191978-9	318	191978-9
350	194160-9	350	194160-9

Carbon Brush for Cordless tool

424	191966-6	424	191966-6
430	191971-3	430	191971-3
434	193466-2	434	193466-2
440	194427-5	440	194427-5
441	194435-6	441	194435-6
442	194928-3	442	194928-3
448	196854-2	448	196854-2