



INDUSTRIAL PLUGS




Screw connection

Ref.	Contacts	Ampere	Volt	IP
902131A	2P+T	16	230	44
902142A	3P+T	16	400	44
902152A	3P+N+T	16	400	44
902133A	2P+T	32	230	44
902144A	3P+T	32	400	44
902154A	3P+N+T	32	400	44



Screw connection


Ref.	Contacts	Ampere	Volt	IP
902431A	2P+T	16	230	67
902442A	3P+T	16	400	67
902452A	3P+N+T	16	400	67
902433A	2P+T	32	230	67
902444A	3P+T	32	400	67
902454A	3P+N+T	32	400	67



Screw connection

Ref.	Contacts	Ampere	Volt	IP
902435A	2P+T	63	230	67
902446A	3P+T	63	400	67
902456A	3P+N+T	63	400	67
902437A	2P+T	125	230	67
902448A	3P+T	125	400	67
902458A	3P+N+T	125	400	67

PHASE INVERTER PLUG



Screw connection

Ref.	Contacts	Ampere	Volt	IP
936142A	3P+T	16	400	44
936152A	3P+N+T	16	400	44
936144A	3P+T	32	400	44
936154A	3P+N+T	32	400	44